

INSTALLATION INSTRUCTIONS

51382 & 51383 APPLICATIONS

Make	Model
Infiniti	QX56
Nissan	Armada
Nissan	Frontier
Nissan	Pathfinder
Nissan	Pathfinder Armada
Nissan	Titan
Nissan	Titan XD
Nissan	Xterra

BRAKE CONTROL HARNESS



NOTICE


All steps must be followed to ensure the CURT brake control harness will function properly. Once installed, test for proper function by following the brake control unit instruction manual.

Vehicles not equipped with an OEM trailer tow package, may require fuses and relays to complete output and battery feed circuits (sold separately). Consult owners manual for locations.

LOCATION GUIDE

Representative vehicle shown below

BH1 - Under dash, left of steering column, near emergency brake pedal



INSTALLATION / SAFETY INSTRUCTIONS

Step 1

Locate the 6-pin, vehicle brake control harness connector under the dash, to the left of the steering column. It will be taped to another harness near the emergency brake pedal. The connector will be similar to that on the CURT brake control harness.

Step 2

Insert the connector on the CURT brake control harness into the vehicle connector. Make sure the connector is fully inserted with locking tabs in place.

Step 3

Insert the brake control harness's black connector into the brake control's quick plug connector. Secure the brake control harness with the provided cable ties, avoiding any pinch points.

Step 4

Complete the installation using the brake control instructions. Mount the unit as directed and perform test procedures as instructed in the brake control user manual.